

Planning & Building Department - Bureau of Building TEL:(510) 238-3381 - TDD:711 for CA Relay Service

Website: https://www.oaklandca.gov/services/leadabatement

Instructions for filling out the Lead Based Paint Work Plan

Complete top part of form:

- What lead work is planned? Removing lead paint, repairing/replacing lead flashing, moving lead bricks, encapsulating lead weights, other?
- What type and quantity of LCM? Paint, pipe, sheeting, bricks, weights, other? How much in sq. ft., linear feet, number, other? Percent in paint, 99.9% solid lead, lead alloy (check Safety Data Sheet)?

Complete all sections of the form, add items where needed:

- 1. Tools and equipment that will disturb Lead Based Paint
- 2. Precaution for warning and protecting building occupants or others
- 3. Preparation and work procedures
- 4. Personal Protective Equipment
- 5. Employee Training
- 6. Clean up Procedures
- 7. Waste Disposal
- 8. Property Owner (Owner Occupied), Contractor, Project manager, supervisor or project lead signs the work plan *Before the work*
- 9. Competent person signs the work plan Before the work
- 10. Employees read/understand/sign work plan Before the work

After work is completed:

- Call for inspection and provide the self-certification of Lead Based paint work remediation/abatement completion.
- Project may opt to keep their Lead Work Plan and permit records for future verification or financial matters.



Planning & Building Department - Bureau of Building TEL:(510) 238-3381 - TDD:711 for CA Relay Service

Website: https://www.oaklandca.gov/services/leadabatement

Lead Work Plan

A Lead Work Plan is required when presumed or confirmed Lead Based Paint will be disturbed during paint or construction activities as per Oakland Municipal Code 15.08 Section 5. Article 8

Address		Location (Exterior, Interior, Exterior & Interior)				
Description of Wor	k					
Type and Quantity	of Lead Containing Material (LCM)	If Kı	nown. If not known please enter NA.			
% of lead in material(s) as per Lead Risk Assessment (if known, if not known please enter NA)			Sample Source (if applicable): Lead Risk Assessment Consultant Other			
Project schedule	Expected start date		Expected completion date			

- Workers must review and sign this Lead Work Plan prior to starting work. Workers must understand this plan and be trained in lead work practices and the systems and equipment that will be used.
- > If Owner occupant will be performing all of the work without any sub contractors or workers only the owner needs to prepare this plan, understand correct Lead Based Paint containment, and sign this workplan.
- > Address other hazards relevant to the work by following specific program requirements for those hazards (le; Asbestos).
- > Post this Lead Work Plan at the worksite for the duration of work activities.
- > If any of the project conditions change, revise the work plan to address the changes.



Planning & Building Department - Bureau of Building TEL:(510) 238-3381 - TDD:711 for CA Relay Service

Website: https://www.oaklandca.gov/services/leadabatement

TOOLS, SAFE WORK PRACTICES, WORKER ACKNOWLEDGEMENT, CLEAN UP PROCEDURES

1. Tools and equipment used that will disturb Lead Based Paint (check all that apply)					
	Paint scraper		Rotohammer with HEPA vacuum dust attachment		
	Hand trowel		Power saw		
	Pry bars		Grinder		
	Hammer		Drill		
	Pressure washer (1000 to 1500 psi)		Wire brush		
	Scraper		Mechanical lifting device		
	Soldering Iron		Other:		
	Welding equipment		Other:		
	Torch		Other:		
2. P	recautions for warning and protecting building o	occu	pants or others		
	Post lead warning sign(s) around worksite		Review any SDS of chemical used with employees prior to start		
	perimeter		of project and provide copy on the job site		
	Close off work area to public		If multiple stories, install OSHA compliant scaffold and netting		
			on the exterior of scaffolding to control dust		
	Notify tenants of work schedule and provide copy		Other:		
	of Lead Work Plan				
3. S	afe work procedures (include controls and work	pra	ctices to minimize employee exposures)		
	Interior locations: Erect a sealed containment		Use local exhaust ventilation when cutting, soldering, torching		
	structure to isolate lead contaminated materials		or welding lead containing materials.		
	from entering occupied areas when working		or weiging lead containing materials.		
	inside. Provide negative air exhaust ventilation				
	with HEPA filters.				
	Exterior Location: Tape plastic sheeting below		Wipe off walls with damp rags		
	work area to catch debris and prevent from		,		
	contaminating equipment, soil or entering storm				
	or sanitary sewer conveyance systems.				
	Provide portable tools with dust collection		Use shaving cream or sponge method when drilling into building		
	shrouds and connect to vacuum systems with		materials		
	HEPA filtration.				
	HEPA Vacuum (do not use compressed air)		Rotate workers to reduce exposure time		
	Wet mist debris before collection		Other:		
	For pressure washing, place catch mat below work		Other:		
			Other:		



Planning & Building Department - Bureau of Building TEL:(510) 238-3381 - TDD:711 for CA Relay Service

Website: https://www.oaklandca.gov/services/leadabatement

4. P	4. Personal Protective Equipment						
Respirator Type:			Safety glasses/goggles				
	Cartridge:						
	Coveralls		Disposable hood				
	Shoe covers		Other:				
	Gloves		Other:				
5. A	ir Monitoring						
	Arrange air monitoring with EH&S		Previous air monitoring has shown that employee exposures are				
			below the AL for	this w	ork/		
	Personal Exposure		Clearance Sampling				
	Area Monitoring		Other:				
	Air monitoring results		Other:				
6. I	Employee(s) trained to work under this plan						
Nar	me (print)	Cur	rent Training (w	ithin	last year)		
			Lead awareness		Lead worker		Respiratory protection
			Lead awareness		Lead worker		Respiratory protection
			Lead awareness		Lead worker		Respiratory protection
			Lead awareness		Lead worker		Respiratory protection
			Lead awareness		Lead worker		Respiratory protection
7. C	lean up procedures						
	HEPA vacuum		Remove contaminated clothing/PPE before exiting worksite.				
	Clean equipment with soap and water or other		HEPA vacuum any debris from plastic, roll plastic and tape ends				
	effective cleaning agent		closed and seal in 6 mil plastic bags.				
Ш	Clean and disinfect respirator	Ш	Tape ends of HEPA vacuum hoses when not in use. Return to designated storage room when finished.				
	Remove all disposable contaminated clothing and		Conduct surface sampling for lead using recommended surface				
	package for waste disposal		contamination limit of:				
			$\mu g/ft^2$				
	Wash hands and face with soap and water before		Other:				
	exiting work area.						
	Remove all contaminated clothing/PPE before		Other:				
	leaving containment. Place in double sealed bags						
	and label.						
8. Disposal							
	Lead contaminated materials disposed as per EPA RRP requirements.		Recycle lead mate	erials	as follows:		
	Lead contaminated water disposed as per EPA		Other:				
	RRP Requirements		Other:				
			Other:				



Planning & Building Department - Bureau of Building TEL:(510) 238-3381 - TDD:711 for CA Relay Service

Website: https://www.oaklandca.gov/services/leadabatement

9. Work plan approval(s): By signing below, I certify that all required precautions including, but not limited to, wearing of proper protective equipment and clothing, participation in a medical surveillance program if necessary, and following the procedures referenced above will be followed during this project. These employees have received appropriate training in the tasks to be performed and understand the risks associated with working with lead-containing material.

Name of property owner, project manager, supervisor, or lead	Signature	Date
10. Reviewed by Competent Person* (name)		

^{*}Project manager, supervisor, or lead may also be the Competent Person, if they meet the definition of a Competent Person.

11. Employee(s) have reviewed and understand the work under this lead work plan				
Name (print)	Signature	Date		

THIS WORK PLAN MUST BE AVAILABLE AT THE JOB SITE.



Planning & Building Department - Bureau of Building TEL:(510) 238-3381 - TDD:711 for CA Relay Service

Website: https://www.oaklandca.gov/services/leadabatement

LEAD BASED PAINT WORK COMPLETION SELF-CERTIFICATION

Address	LBP or B/RBC Permit Number				
Name of Responsible Party					
Owner	Contractor EPA RRP Certif	icate Number			
	EPA RRP Certificate Expiration Da	te			
EPA RRP/CDPH Lead Constructi	on Requirements VERIFIC	CATION			
Complete, sign and submit this self-certification of completion of Lead Based Paint work, to the Building Inspector at final inspection.					
I have performed and inspected the work and have received sufficient documentation to verify and certify that the project identified above was painted in accordance with the requirements of the Environmental Protection Agency Renovate, Repair, Right or California Department of Public Health Lead Construction Requirements applicable at the time where lead-based paint was disturbed as part of paint and/or construction activities.					
Signature of Person responsible for EPA RRP/ CDPH I	_BP Requirements	Date			
Name of Person responsible for EPA RRP/CDPH LBP	compliance (Please Print)	Phone			
Email Address for Person responsible for EPA RRP/CD	PH LBP Compliance				